

### **RESET to Default System Value:**

- Please scan the "DEFAULT" setup barcode at the right.  
As the memory setup parameter cannot be deleted, please initialize the memory first then delete the data in the memory.



- When CYCLOPS 2 has been configured as "reverse barcode scanner", please scan the "reversed DEFAULT" setup barcode at the right.



Kitapçığınızda bulunan koyu renkli barkodu okutarak siyah zeminli barkodları okutma ayarını açabilirsiniz.

### **Memory Initialization:**

Memory Initialization will delete all data and values in the memory.  
Please scan the barcode at the right side which can initialize the memory.

- ※ **Please note:** there is no way to restore the data deleted after memory initialization.

