Argox AS-8520

Deep Sleep Mode

The WIRELESS imager can be placed into **Deep Sleep Mode** after this programmed duration (since the units' last scanning activity). Press its trigger to wake the imager form this mode.

- **Disable Deep Sleep Mode** (**Default**)

||||| | |||| | || ||||| ||||| ||||| |

- **Duration 10 minute**s - Force imager into deep sleep mode if there is no barcode read in 10 minutes.

||||| | |||| | || ||||| ||||| ||||| |

- **Duration 30 minute**s - Force imager into deep sleep mode if there is no barcode read in 30 minutes.

| | ||||| | | ||||

- **Duration 60 minutes** - Force imager into deep sleep mode if there is no barcode read in 60 minutes.

||||| | |||| | || ||||| ||||| ||||| |

- **Duration 90 minutes** - Force imager into deep sleep mode if there is no barcode read in 90 minutes.

| | ||||| | | ||||