


Restore Custom Defaults
~3\$P,HA00,P<CR>



Enter Configuration
~3\$P<CR>



Good Read Beep Volume: Beeper Off,Power On Alert: No Indication,BT Cradle Beep: Disable,Disconnect Beep: Enable,ACK Beep: ACK Beep Disabled
~3\$CBPVO00,CBPPU00,CBTCB00,CBTDB01,CBTAB00<CR>



ule 1,ule 2
~3\$U00000008554C4532000E0A0A,U0008000C0A0A7B0A7D0A0A0A040A0A0A<CR>



Exit Configuration
~3\$P<CR>

