

Enter Programming Mode : Switch



INTERFACE_TYPE : RS232-STD



Exit Programming Mode : Switch

