

# Interface Selection

START / END	
PROGRAMMING bar codes	
	RS-232 Standard
	USB Keyboard
	USB COM Interface

START / END

