

Enter Programming Mode : Switch



INTERFACE_TYPE : USB Keyboard



Exit Programming Mode : Switch

