

ITF 14 Kontrol karakteri aktarsın

*Enter Setup



W010F01

Enable ITF-14 and Transmit Check Digit



W036E0A

Exit Setup



W010F00

ITF 14 Kontrol karakteri aktarmasın

*Enter Setup



W010F01

ITF-14 **But Do Not** Transmit Check Digit



W036E02

Exit Setup



W010F00