



Start of Configuration

FUNCTION KEY



ON



Trailer



HT
(TAB)



Set



End of Configuration