



# Beeper Tone


Enter/Exit programming




High Frequency




Medium Frequency




Low Frequency




Short sound duration (20msec.)




Long sound duration (100msec.)



Medium sound duration (50msec)



Disable



Enter/Exit programming

