



W010F01

*Enter Setup



W010F00

Exit Setup

Good Read Beep



W041200

Good Read Beep Off



W041204

*Good Read Beep On

Good Read Beep Frequency



WFF10DA

Low



WFF104B

*Medium



WFF1025

High