

Wireless Barcode Scanner 1 User's Manual

Introduction

Wireless barcode scanner transfer the scanned data to receiver wirelessly ,then the receiver transfer data to computer terminal, the scanner is powered by the inserted lithium battery, please charge battery in time if low power.

It is recommended to fully charge the battery on first use. The receiver and scanner have been paired already in default. If you want to re-pair, just scan the pair code on receiver. If the pair code is missing, refer to the 1.8 pairing method.

The setting is divided into scanner part and receiver part. You can restore all settings to factory default with below steps:set scanner to default->pairing scanner with receiver (ignoring this step if paired)->set receiver to default.

“ * ” default setting.

Part one : Scanner Setting

1. Set scanner to default



2. Working mode

Immediate

(The scanned data will be not stored in scanner ,it will be directly transferred to receiver. There will be LED flashing and beeper as reminder if transferring failed.)



*Auto

(The scanned data will be stored in scanner when no signal. Data will be transferred to receiver when signal recover.)

Inventory Input

(The scanned data will be stored in scanner and not transferred to receiver.)



Inventory Output

(All data stored in scanner will be transferred to receiver and the scanner automatically enter the inventory input mode after data is fully transferred.)

Multiple Inventory Output

(Transferred the last time scanned code data, do not need to delete the data, scan the NO.10: Clean the stored data)



3. Engine sleep



10S

*1Min



5Min

10Min



V9.7.2

None



4. Scanner sleep



10S

*1Min



5Min

10Min



30Min

5. Transmission fail sound

OFF



*ON

6. Startup sound

OFF



*ON

7. Beeper

OFF



Short sound

*Middle sound



Long sound

Low frequency



*Medium frequency

High frequency



8. Auto pairing



Note: Scan the barcode,the device will enter into the one minute auto pairing mode (LED flash, beeper sound), re-plug in the receiver, the scanner will be paired successfully. Scan the barcode again if you want to exit the auto pairing mode.

9. Scanner version



10. Clean the stored data



Note: Scan the barcodes and the stored data will be cleaned.

Part two : Receiver Setting

1. Set receiver to default



2. Interface selection

*USB-HID



USB-VCP

3. Keyboard language

*USA



French





German



*8 bit



*Middle sound



Upper case compulsive

UK



6. Parity

*None



Long sound



Lower case compulsive



Turkish-Q



Odd



Low frequency



Upper and Lower case convert compulsive

Danish



7. Stop bits

*1 bit



11. Startup sound

OFF



14. Keyboard function

*OFF



Japan



2 bit



High frequency



ON

15. Num lock

*OFF



Spanish



8. NAK

*ACK/NAK OFF



12. Terminator

None



16. Inter-character delay

*None



Italian



ACK/NAK ON



9. CTS/RTS

*CTS/RTS OFF



*Enter (0x0D)



10ms

4. Baud rate


4800



CTS/RTS ON



Return (0x0A)



20ms

*9600



10. Beeper tone

Sound OFF



Tab (0x0D+0x0A)



50ms

19200



Space (0x20)



200ms

115200



5. Data bits

7 bit



Short sound



13. Caps lock

*None



17. Receiver version

